

Congratulations!

You are now the proud owner of a Bluefig wheeled carrier! We are confident you will enjoy your carrier and it will provide years of service to you. These comprehensive instructions were designed to guide you through the assembly process. Should you require any further assistance, please do not hesitate to call **1-800-688-8442** and we will do our best to guide you further.

Phillips Screwdriver Required!



Assembly of Side Support Frame

1. Locate zipper opening on bottom of side panel



**For TB23, DS19 &
DS23, & STB Series**

2. Insert steel frame into side panel as pictured



Repeat this process for opposite side of bag..

3. Ensure steel frame is fully inserted and zip the panel shut.



4. Locate the baseplate and insert the square metal tubes into the wheel set completely.

NOTE:

The set screw holes in the tubes will only line up properly if tubes are fully inserted.



5. Align holes to ensure proper screw insertion. Locate screws in plastic bag accompanying unit.



QUESTIONS?
Call **1-800-688-8442**